OWNER'S GUIDE



22" REAR DISCHARGE ROTARY MOWER

Model Number 125-376-000

Important:

Read Safety Rules and Instructions Carefully

Thank you for purchasing an American-built product.

PRINTED IN U.S.A.

FORM NO. 770-4048

INDEX

Safe Operation Practices 3
Assembly 4
Controls 9
Operation 9
Adjustments 12
Lubrication 12
Maintenance 13
Off-Season Storage 15
Trouble Shooting Chart 17
Illustrated Parts 18, 20
Repair Parts List 19, 21
Parts Information ..... Back Cover

Instructions given with this symbol are for personal safety. Be sure to follow them.

LIMITED WARRANTY

For one year from the date of original retail purchase, MTD PRODUCTS INC will either repair or replace, at its option, free of charge, F.O.B. factory or authorized service firm, any part or parts found to be defective in material or workmanship. Transportation charges for the movement of any power equipment unit or attachment are the responsibility of the purchaser. Transportation charges for any parts submitted for replacement under this warranty must be paid by the purchaser unless such return is requested by MTD PRODUCTS INC.

This warranty will not apply to any part which has become inoperative due to misuse, excessive use, accident, neglect, improper maintenance, alterations, or unless the unit has been operated and maintained in accordance with the instructions furnished. This warranty does not apply to the engine, motor, battery, battery charger or component parts thereof. Please refer to the applicable manufacturer's warranty on these items.

This warranty will not apply where the unit has been used commercially.

Warranty service is available through your local authorized service dealer or distributor. If you do not know the dealer or distributor in your area, please write to the Customer Service Department of MTD.

The return of a complete unit will not be accepted by the factory unless prior written permission has been extended by MTD.

This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

WARNING

This unit is equipped with an internal combustion engine and should not be used on or near any unimproved forest-covered, brush-covered or grass-covered land unless the engine's exhaust system is equipped with a spark arrester meeting applicable local or state laws (if any). If a spark arrester is used, it should be maintained in effective working order by the operator.

In the State of California the above is required by law (Section 4442 of the California Public Resources Code). Other states may have similar laws. Federal laws apply on federal lands. A spark arrester muffler is available at your nearest engine authorized service center.

To reduce the potential for any injury, comply with the following safety instructions. Failure to comply with the instructions may result in personal injury.

SAFE OPERATION PRACTICES FOR WALK-BEHIND MOWERS

TRAINING

1. Read this owner's manual carefully in its entirety before attempting to assemble or operate this machine. Be completely familiar with the controls and the proper use of this machine before operating it. Keep this manual in a safe place for future and regular reference and for ordering replacement parts.
2. Your rotary mower is a precision piece of power equipment, not a plaything. Therefore, exercise extreme caution at all times.
3. Never allow children to operate a power mower. Only persons well acquainted with these rules of safe operation should be allowed to use your mower.
4. No one should operate this unit while intoxicated or while taking medication that impairs the senses or reactions.
5. Keep the area of operation clear of all persons, particularly small children and pets. Stop engine when they are in the vicinity of your mower. Although the area of operation should be completely cleared of foreign objects, an object may have been overlooked and could be accidently thrown by the mower in any direction and cause serious personal injury to the operator or any others allowed in the area.

PREPARATION

1. Thoroughly inspect the area where the equipment is to be used. Remove all stones, sticks, wire, bones and other foreign objects which could be picked up and thrown by the mower in any direction and cause serious personal injury to the operator or any others allowed in the area.
2. Do not operate equipment when barefoot or wearing open sandals. Always wear substantial footwear.
3. Do not wear loose fitting clothing that could get caught on the mower.
4. Check the fuel before starting the engine. Gasoline is an extremely flammable fuel. Do not fill the gasoline tank indoors, while the engine is running, or while the engine is still hot. Wipe off any spilled gasoline before starting the engine as it may cause a fire or explosion.
5. Disengage the self-propelled mechanism or drive clutch on units so equipped before starting the engine.
6. The blade control handle is a safety device. Never attempt to bypass its operation. Doing so makes the safety device inoperative and may result in personal injury through contact with the rotating blade. The blade control handle must operate easily in both directions.
7. Never attempt to make a wheel or cutting height adjustment while the engine is running.
8. Mow only in daylight or in good artificial light.
9. Never operate the equipment in wet grass. Always be sure of your footing. A slip and fall can cause serious personal injury. Keep a firm hold on the handle and walk, never run.

OPERATION

1. Do not change the engine governor settings or overspeed the engine. Excessive engine speeds are dangerous.
2. Do not put hands or feet near or under rotating parts. Keep clear of the discharge opening at all times as the rotating blade can cause injury.
3. Stop the blade when crossing gravel drives, walks or roads.
4. After striking a foreign object, stop the engine, remove the wire from the spark plug, and thoroughly inspect the mower for any damage. Repair the damage before restarting and operating the mower.
5. If the equipment should start to vibrate abnormally, stop the engine and check immediately for the cause. Vibration is generally a warning of trouble.
6. Shut the engine off and wait until the blade comes to a complete stop before removing the grass catcher or unclogging the chute. The cutting blade continues to rotate for a few seconds after the engine is shut off. Never place any part of the body in the blade area until you are sure the blade has stopped rotating.
7. Before cleaning, repairing or inspecting, make certain the blade and all moving parts have stopped. Disconnect the spark plug wire, and keep the wire away from the spark plug to prevent accidental starting.
8. Do not run the engine indoors.
9. Mow across the face of slopes, never up-and-down. Exercise extreme caution when changing direction on slopes. Do not mow excessively steep slopes. Always be sure of your footing. A slip and fall can cause serious personal injury.
10. Always disconnect electric mowers (line operated) before cleaning, repairing or adjusting.
11. Never operate mower without proper guards, plates or other safety protective devices in place.
12. **DO NOT OPERATE** this mower with the chute door open, unless the complete grass catcher is properly mounted on the mower.

MAINTENANCE AND STORAGE

1. Check the blade and engine mounting bolts at frequent intervals for proper tightness.
2. Keep all nuts, bolts, and screws tight to be sure the equipment is in safe working condition.
3. Never store the equipment with gasoline in the tank inside of a building where fumes may reach an open flame or spark. Allow the engine to cool before storing in any enclosure.
4. To reduce fire hazard, keep the engine free of grass, leaves, or excessive grease.
5. Check the grass catcher bag frequently for wear or deterioration. For safety protection, replace only with new bag meeting original equipment specifications.

NOTE

This unit is shipped WITHOUT GASOLINE or OIL. After assembly, see separate engine manual for proper fuel and engine oil recommendations.



FIGURE 1.



FIGURE 2.



FIGURE 3.

ASSEMBLY

Contents of Hardware Pack: (See figure 1)

A (2) Hairpin Cotters
B (2) Curved Carriage Bolts
C (2) Lock Washers
D (2) Hex Nuts 5/16-18 Thread
E (1) Plastic Cap
F (2) Phillips Head Screws
G (2) Cable Ties
H (2) Plastic Plugs
I (2) Front Hub Caps (Not Shown)
J (2) Ignition Keys (Not Shown)

1. Remove the lawn mower, loose parts, hardware pack and literature from the carton. Make certain all parts and literature have been removed before the carton is discarded.
2. Extend all control cables and place on the floor. Be careful not to bend or kink control cables.
3. A plastic strap secures the height adjustment handle, located on the left side of the deck, to the handle mount bracket for shipping purposes. Cut and remove the plastic strap.
4. Place bottom hole in lower handle in position over weld pins in handle mount brackets on deck. Make certain the instruction label on the lower handle can be read from the operating position. Secure by placing two hairpin cotters (A) in inner hole on weld pins. The inner hole is for operation. The outer hole is for storage. See figure 2.

NOTE

It may be necessary to bend the ends of the lower handle inward slightly to obtain a snug fit against the bracket.

5. Place handle panel and upper handle in position over lower handle. Control housing should be on the **left** side of the handle. Secure with two curved carriage bolts (B), lock washers (C) and hex nuts (D) as shown in figure 3.

NOTE

Reference to left or right side of machine is determined from operator's position at the handle facing forward.



FIGURE 4.

6. The brake cable is attached to the engine, and has a "Z" fitting on the loose end. Route the brake cable under the lower handle. Place end of cable into the upper hole on the bottom of the control housing, and through the slot on the side of the housing as shown. The angle of the flange on the plastic fitting must be positioned downward as shown in figure 4. Be careful not to bend or kink the cable.

WARNING

The cable must be assembled as shown for proper blade brake operation.



FIGURE 5.

7. Snap the plastic fitting on the end of the cable into the control housing.
8. Hook the "Z" end of the brake cable into the hole in the blade control handle. See figure 5.
9. Move throttle control lever on handle forward until it stops in FAST position. (**Do not** push all the way forward to CHOKE position.) See figure 6.
10. The throttle control cable is attached to the upper handle. Hook the "Z" end of the throttle control cable into the hole in the control lever on the engine. See figure 6.
11. Loosen the screw on the cable clamp shown in figure 6. Slip the control casing under the clamp.
12. Slide the throttle control lever on the engine as far toward the outside of the engine as it will go **easily** as shown in figure 6. (**Do not** force it into the extreme outside position, which is the CHOKE position.) Then tighten the screw to secure the throttle control cable. Be certain the clamp is positioned so it holds the cable in a straight line, parallel to the engine shroud.
13. Loosen the screw on the clamp on the side of the engine. Secure the cable **away from the muffler.** Be careful not to bend or kink the cable. Tighten the screw.



FIGURE 6.



FIGURE 7.

14. The drive clutch control cable is attached to the deck. Attach the cable to the lever in the clutch control housing, located in the middle of the upper handle, as follows.
    a. Place the lead ball end of the cable into the fitting provided in the end of the clutch control lever. Slip the braided wire into the vertical slot as shown in figure 7.



FIGURE 8.

    b. Slide the braided wire around in the horizontal slot. See figure 8.
    c. Place the plastic fitting on the control cable into the first adjustment position in the clutch control housing. See figure 7.
    d. Secure the plastic cap (E) to the clutch control housing using the two Phillips head screws (D). See figure 8.

WARNING

Drive clutch adjustment must be checked before the unit is operated, as described in the operation section.



FIGURE 9.

15. Plug the large plug on the wire harness into the ignition switch. Plug the small plug on the wire harness into the battery pack lead. See figure 9.



FIGURE 10.

16. Secure all control cables to handle with cable ties (G) provided. See figure 10.
17. Insert plastic plugs (H) into holes in the top rear of the deck by slipping one end of plug into hole, then pressing down on the other end of plug.
18. Attach hub caps to wheels by lining up cap with hub of wheel. Push to snap in place.
19. Check **all** nuts and bolts for correct tightness.



FIGURE 11—Bag with Flip Top Opening.

Grass Catcher Assembly

There are two different types of grass bags, both with and without flip top openings. Follow the instructions which pertain to your unit.

1. Grass Bags with Flip Top Opening:
   a. Attach bag to rear frame by inserting one end of frame into pocket from inside bag. See figure 11A.
   b. Thread all material on one side of frame before working it around the frame.
   c. After threading, both ends of frame should be inside the bag. See figure 11B.



FIGURE 12.

2. Join the upper frame and lower frame assembly as shown in figure 12.



FIGURE 13.

3. Grass Bags without Flip Top Opening: Place bag over frame (black plastic side is the bottom of bag). Upper frame goes to the top of bag.
4. Secure bag to frame by slipping plastic channels on bag over frame. See figure 13.
5. Grass Bags with Flip Top Opening: Close top of bag by stretching loose material over the end of the frame.

WARNING

Never operate the mower with the bag open.

To Attach Bag To Mower

WARNING

DO NOT operate the mower with the chute door open unless the complete grass catcher is properly mounted on the mower.



FIGURE 14.

1. Attach the grass catcher frame to grass catcher hitch bracket on rear of the mower by hooking grass catcher into hooks on grass catcher hitch bracket. See figure 14.
2. Lift the rear of grass catcher up. The roller on the grass catcher will push the chute door on the mower open. See figure 14.

NOTE

Figure 14 is shown with the chute door open for clarity only.



FIGURE 15.

The grass catcher frame will snap into place, secured by the lock lever. See figure 15.

To remove the grass catcher, unhook the lock lever and slip the grass catcher off the unit. See figure 15.

CONTROLS



FIGURE 16.

BLADE CONTROL HANDLE

WARNING
THIS CONTROL MECHANISM IS A SAFETY DEVICE. NEVER ATTEMPT TO BYPASS ITS OPERATIONS

The blade control handle is located on the upper handle of the mower. See figure 16. The blade control handle must be depressed in order to operate the unit. Release the blade control handle to stop the engine and blade.

WARNING

The blade will be rotating whenever the engine is running.

THROTTLE CONTROL

The throttle control is located on the left side of the upper handle. It is used to regulate the engine speed. The engine should be started with the engine in the CHOKE position.

WARNING

The throttle control cannot be used to stop the engine.

DRIVE CLUTCH CONTROL

Squeezing the drive clutch control engages the drive mechanism to the rear wheels. Releasing the clutch control stops the rear wheels from driving. Release the drive clutch control to slow down when negotiating an obstacle, making a turn or stopping. See figure 16.

IGNITION SWITCH

The ignition switch is located on the right side of handle panel. It is used for **starting only.** See figure 16.

HEIGHT ADJUSTMENT HANDLE

The height adjustment handle is located on the left side of the deck. The handle may be placed in one of five cutting height positions. Push the handle to the left and then either forward or backward to raise or lower the cutting height. See figure 17.



FIGURE 17.

OPERATION

Caution
Do Not Operate Mower Unless This Guard Or Entire Grasscatcher Is In Its Proper Place.
DANGER
KEEP HANDS and FEET AWAY
2196

FIGURE 18.

Keep hands and feet away from the chute area on cutting deck. See figure 18.

NOTE

For shipping purposes your mower is set with the wheels in a low cutting height position. For best results raise the cutting position until it is determined which height is best for your lawn. See control section.



FIGURE 19.

BEFORE STARTING

WARNING

The battery contains corrosive fluid and toxic material. HANDLE WITH CARE. Keep away from children. Do not puncture, disassemble, mutilate or incinerate. Explosive gases could be vented during charging or discharging. Use in a well-ventilated area, away from sources of ignition.

1. Charge battery for 16 hours before initial use. DO NOT CHARGE LONGER THAN 20 HOURS.

CAUTION

Use only the battery charger supplied with this mower.

To charge the battery, proceed as follows See figure 19.

Always plug charger lead into battery pack lead before inserting battery charger plug into 120 volt standard household outlet.

After charging, disconnect battery charger plug from household outlet first, then disconnect charger lead from battery pack lead.

WARNING

Do not remove the battery pack from the handle panel for any reason other than replacement. When replacing the battery pack, refer to instructions in Maintenance section.

2. Fill sump with oil as instructed in the separate engine manual packed with your unit.
3. Fill fuel tank, using clean, fresh, lead-free, low-lead or regular grade leaded gasoline. Fill tank completely!
   DO NOT MIX OIL WITH GASOLINE.
4. Attach spark plug wire to spark plug.
5. Open fuel shut-off valve, located beneath the fuel tank. See figure 20.



FIGURE 20.

6. Before each use, check for proper drive clutch operation by performing the following before starting the engine:

   With the drive clutch control released, push mower forward. It should move freely. **Pull mower backward. It should move freely.**

With the drive clutch control engaged (lever squeezed against upper handle), push mower forward. It should move freely. Pull mower backward. The rear wheels should lock up. If they do not, adjust the clutch control as specified under Drive Clutch Control Adjustment.

TO START ENGINE AND ENGAGE BLADE

WARNING

When starting the unit for the first time, face the mower against a solid object such as a wall, fence, etc. Start the unit, and if it shows any signs of motion with the drive clutch control disengaged, shut the engine off immediately. Check the position of the drive clutch control cable. The plastic fitting must be assembled in the first adjustment position inside the housing, all the way to the right, as shown in figure 7.

1. Move the throttle control lever to CHOKE position.
2. Standing behind the unit, depress the blade control handle and hold it against the upper handle as shown in figure 21.
3. Turn the ignition key to the right to start the engine. Release the key after engine starts.
4. After engine starts, move throttle control to FAST or desired engine speed.



FIGURE 21.

TO STOP ENGINE AND BLADE

1. Release the blade control handle to stop the engine and blade.

WARNING

The blade continues to rotate for a few seconds after the engine is shut off.

2. Disconnect the spark plug wire and ground it against the engine to prevent accidental starting while equipment is unattended.

USING YOUR ROTARY MOWER

Be sure that lawn is clear of stones, sticks, wire, or other objects which could damage lawn mower or engine. Such objects could be accidently thrown by the mower in any direction and cause serious personal injury to the operator and others.

Operate a new engine at intermediate speeds and light load for the first few hours as you would a new automotive engine.

For best results, do not cut wet grass because it tends to stick to the underside of the mower, preventing proper discharge of grass clippings, and could cause you to slip and fall. New grass or thick grass may require a narrower cut. Blade speed should be adjusted to the condition of the lawn.

The best mowing pattern is one that allows the clippings to discharge towards the uncut part of the lawn. This permits recutting of the clippings to further pulverize them. When cutting high weeds, discharge towards cut portion, then recut at right angles to first direction.

For best results, cut off one-third or less of the total length of the grass. Lawn should be cut in the fall as long as there is growth.

This mower is designed to be operated at full throttle to give you the best cut and do the most effective job of bagging the cut grass.

IMPORTANT

If you strike a foreign object, stop the engine. Remove wire from spark plug, thoroughly inspect the mower for any damage, and repair the damage before restarting and operating the mower. Extensive vibration of the mower during operation is an indication of damage. The unit should be promptly inspected and repaired.

ADJUSTMENTS

WARNING

Do not at any time make any adjustment to lawn mower without first stopping engine and disconnecting spark plug wire.

DRIVE CLUTCH CONTROL ADJUSTMENT

If the unit does not self-propel with the drive clutch control engaged, remove the plastic cap from beneath the drive clutch control housing. Move the plastic fitting on the control cable to the next adjustment position on the left. Reassemble the plastic cap and retest. See figure 22.



FIGURE 22.

THROTTLE

The throttle control wire assembly can be adjusted if necessary. Refer to steps 9 through 13 of Assembly Instructions.

CARBURETOR ADJUSTMENTS

WARNING

If any adjustments are made to the engine while the engine is running (e.g. carburetor), keep clear of all moving parts. Be careful of heated surfaces and muffler.

Minor carburetor adjustment may be required to compensate for differences in fuel, temperature, altitude and load.

Refer to the separate engine manual packed with your mower for carburetor adjustment information.

LUBRICATION

WARNING

Always stop engine and disconnect spark plug wire before cleaning, lubricating or doing any kind of work on lawn mower.

Blade Control—Lubricate the pivot points on the blade control handle and the brake cable at least once a season with light oil. See figure 23. The blade control must operate freely in both directions.



FIGURE 23.

Discharge Chute Door Mechanism—The torsion spring and pivot point should be lubricated periodically with light oil to prevent any rust or binding. Door must work freely.

Wheels—Mower is provided with ball bearing wheels. Lubricate at least once a season with light oil. Also, if the wheels are removed for any reason, lubricate the surface of the axle bolt and the inner surface of the wheel with light oil. A 4 oz. plastic bottle of light oil lubricant is available. Order part number 737-0170. Engine oil may also be used.

Engine—Follow engine manual for lubrication instructions.

Throttle—Periodically lubricate throttle control lever and throttle wire assembly with a few drops of light oil for ease of operation.

Chain—Periodically lubricate the chain with appropriate chain lubricant. A stiff or rusted chain can be restored by removing the master link, soaking the chain in kerosene or a solvent, letting it air dry and wiping the chain with a rag saturated with lubricant.

If the rotary mower is operated in a sandy area, the chain should not be lubricated with oil. Excessive oil on a chain will collect dirt and cause excessive wear on the chain and sprockets.

Model 376

PARTS LIST FOR MODEL 376 ROTARY MOWER

REF. NO.	PART NO.	COLOR CODE	DESCRIPTION	NEW PART
1	718-0145		Grip	
2	731-0585		Rear Flap Ass'y.	
3	731-0609		Control Handle—L.H.	
4	735-0639		Spark Plug Insulator	
5	742-0125		22" Blade	
6	746-0472		Throttle Wire—58.0"	
7	749-0505		Lower Handle (Chrome)	
	749-0504		Lower Handle (Painted)	
8	—		Engine	
9	14845		Grass Catcher Lock Lever	
10	14582		Grass Catcher Lower Frame Ass'y.	
11	712-0267		Hex Nut 5/16-18 Thd.*	
12	726-0100		Push Nut 3/8" Rod	
13	731-0430		Plastic Roller	
14	731-0564		Plug	
15	732-0357		Extension Spring	
16	736-0119		L-Wash. 5/16" I.D.*	
17	738-0155		Shld. Bolt .437" Dia. x .162"	
18	14593		Handle Brkt. Ass'y.—R.H.	
19	14597		Handle Brkt. Ass'y.—L.H.	
20	710-0588		Hex Hd. Self-Tap Scr. 1/4-20 x 1.00" Lg.	
21	15248		Rear Baffle—L.H.	
22	15254		Side Baffle	
23	710-0167		Carriage Bolt 1/4-20 x .50" Lg.	
24	15879		Reinforcement Brkt.	
25	710-0782		Hex Wash. Hd. Drill Scr. 1/4 x .75" Lg.	
26	712-0287		Hex Nut 1/4-20 Thd.*	
27	736-0329		L-Wash. 1/4" I.D.*	
28	15568		Front Cover Plate	
29	15253		Left Strap	
30	710-0776		Hex Wash. Hd. AB-Tap Scr. 1/4 x .62" Lg.	
31	710-0783		Fl-Hd. Phil. Scr. #8-32 x .38" Lg.	
33	710-0331		Hex Bolt 3/8-24 x 2.25" Lg. (Grade 5)	
34	712-0123		Hex Nut 5/16-24 Thd.*	
36	736-0119		L-Wash. 5/16" I.D.*	
37	712-0267		Hex Nut 5/16-18 Thd.*	
38	16360		Battery Plate	N
39	725-1105		Battery Pack	N
42	736-0168		External L-Wash. #8 I.D.	
43	712-0142		Hex Nut #8-32 Thd.	
44	725-0727		Battery Charger	
45	725-1106		Battery Pack Lead	N
46	725-1096		Wire Harness	N
47	725-0873		Ignition Switch	N
48	731-0741		Handle Panel	N
49	746-0477		Control Cable—43.0" Lg.	

REF. NO.	PART NO.	COLOR CODE	DESCRIPTION	NEW PART
51	736-0217		L-Wash. 3/8" I.D. Heavy Duty	
52	736-0119		L-Wash. 5/16" I.D.*	
53	14012		Grass Catcher Hitch Brkt.	
54	15245		Chute Door	
55	710-0654		Hex Wash. Hd. TT-Tap Scr. 3/8-16 x 1.00" Lg.	
56	710-0703		Carriage Bolt 1/4-20 x .75"*	
58	712-0271		Sems Nut 1/4-20 Thd.	
59	719-0253		22" Deck Ass'y.	
60	732-0408		Torsion Spring .34" I.D. x 2.38" Lg.	
61	736-0173		Fl-Wash. .281" I.D. x .73" O.D.	
62	736-0211		Fl-Wash. .285" I.D. x 1.25" O.D. x .060	
63	747-0353		Rod .25" Dia. x 8.25" Lg.	
66	714-0104		Intern. Cot. Pin 5/16" Dia.	
67	726-0192		Cable Tie	
68	725-0201		Ignition Key	
70	710-0796		Truss Mach. B-Tap Scr. #12 x 1.50" Lg.	
71	710-0841		Flat C-Sunk AB-Tap Scr. #10 x .75" Lg.	
72	726-0135		Cap Speed Nut 5/16" Rod	
73	731-0523		Control Panel Half	
74	731-0524		Control Disc Pin	
75	731-0526		Clutch Panel Half	
76	731-0528		Throttle Control Lever	
77	731-0617		Control Cover Half—Upper	
78	731-0618		Control Cover Half—Lower	
79	731-0619		Cable Mtg. Cap	
80	731-0620		Control Lever	
81	749-0437		Upper Handle (Chrome)	
	749-0439		Upper Handle (Painted)	
82	710-0429		Hex B-Tap Scr. #10 x .38	
83	751-0333		Casing Clamp	
84	749-0278		Grass Catcher Upper Frame	
85	764-0171		Grass Bag	
86	746-0463		Drive Clutch Cable—50"	
87	12894		Casing Clamp	
88	710-0899		Hex Sems Scr. #10-32 x .62"	
89	710-0671		Curved Carriage Bolt 5/16-18 x 1.38" Lg.	
92	753-0348		Blade Adapter Kit	
93	710-0888		Hex Bolt 5/16-24 x 1.00" Lg. (Grade 5)	
95	13773		Engine Mounting Cover Plate	
98	777-3458		Control Label—Throttle	
99	753-0360		Kit—Control Housing Comp.	
100	753-0362		Kit—Clutch Control Housing Comp.	
—	8376-000-5		Hardware Pack	

*For faster service obtain standard nuts, bolts and washers locally. If these items cannot be obtained locally, order by part number and size as shown on parts list.

(462—Red Flake)

When ordering parts, if color or finish is important use the appropriate color code shown. (e.g. Red Flake Finish—14005 (462).)

Model 376



NOTE: The engine is not under warranty by the mower manufacturer...If repairs or service is needed on the engine, please contact your nearest authorized engine service outlet. Check the "Yellow Pages" of your telephone book under "Engines—Gasoline."

Find It Fast In The Yellow Pages

NOTE

This instruction manual covers various models and all specifications shown do not necessarily apply to your model. Specifications subject to change without notice or obligation.

MAINTENANCE

NOTE

When tipping the unit, empty the fuel tank and keep engine spark plug side up.

BATTERY PACK REPLACEMENT

Remove the battery pack from the handle panel for replacement only. Do not separate the batteries for any reason. Dispose of batteries properly.

WARNING

Batteries contain sulfuric acid which may cause burns. Do not short circuit or mutilate in any way. Do not put batteries in fire. They may burst or release toxic materials.

When replacing battery pack in handle panel, battery pack must be positioned with the positive terminal to the left hand side and the negative terminal to the right hand side of panel. See figure 24.

Replacing the battery pack incorrectly will cause serious damage.


Positive and Negative Markings are on Top of Battery Pack
Negative Terminal to Right Hand Side of Panel, Standing Behind the Mower
Positive Terminal to Left Hand Side of Panel, Standing Behind the Mower
Red Wire
Black Wire

FIGURE 24.

CUTTING BLADE

A. Removal for Sharpening or Replacement

WARNING

Be sure to disconnect and ground the spark plug wire before working on the cutting blade to prevent accidental engine starting.

Remove the large bolt and lock washer which holds the blade and adapter to the engine crankshaft. Remove the blade and adapter from the crankshaft.

If the blade or blade adapter needs replacing, remove the two small bolts, lock washers and nuts which hold the blade to the adapter.

NOTE

Periodically inspect the blade adapter for cracks, especially if you strike a foreign object. Replace when necessary.

B. Sharpening

Remove the cutting blade by following the directions of the preceding section.

When sharpening the blade, follow the original angle of grind as a guide. It is **extremely important** that each cutting edge receives an equal amount of grinding to prevent an unbalanced blade. An unblanced blade will cause excessive vibration when rotating at high speeds, may cause damage to the mower and could break, causing personal injury.

It is recommended that the blade always be removed from the adapter for the best test of balance. The blade can be tested by balancing it on a round shaft screwdriver. Remove metal from the heavy side until it balances evenly.

C. Reassembly

Before reassembling the blade and the blade adapter to the unit, lubricate the engine crankshaft and the inner surface of the blade adapter with light oil. Lubricating the bolt holes, bolts and inner surface of the nuts with light oil is also recommended. A 4 oz. plastic bottle of light oil lubricant is available. Order part number 737-0170. Engine oil may also be used.

When replacing the blade, be sure to install the blade with the side of the blade marked "Bottom" (or with part number) facing the ground when the mower is in the operating position.

Blade Mounting Torque

3/8" Dia. Bolt 375 in. lb. min., 450 in. lb. max.
5/16" Dia. Bolt 150 in. lb. min., 250 in. lb. max.

To insure safe operation of your unit, **all** nuts and bolts must be checked periodically for correct tightness.

DECK

The underside of mower deck should be cleaned after each period of use as grass clippings, leaves, dirt and other matter will accumulate. This accumulation of grass clippings, etc., is undesirable as it will invite rust and corrosion and may cause an uneven discharge of grass clippings at the next cutting.

The deck may be cleaned by tilting the mower forward or on its side and scraping clean with a suitable tool or by washing with a stream of water from a garden hose.

CAUTION

Do not direct the stream of water at a hot engine as damage to the engine may result.

ENGINE

Refer to the separate engine manual for engine maintenance instructions.

AIR CLEANER

Service air cleaner every 25 hours under normal conditions. Clean every few hours under extremely dusty conditions. Poor engine performance and flooding usually indicates that the air cleaner should be serviced.

To service the air cleaner, refer to the separate engine manual packed with your unit.

SPARK PLUG

The spark plug should be cleaned and the gap reset once a season. Spark plug replacement is recommended at the start of each mowing season; check engine manual for correct plug type and gap specifications.

STORAGE OF THE BATTERY

The battery must be stored with a full charge. A discharged battery will freeze.

IMPORTANT

All batteries discharge during storage.

Recharge battery every two months and before returning to service. Refer to charging instructions on page 10.

BELT REMOVAL AND REPLACEMENT

1. Disconnect the spark plug wire and ground it.
2. Drain the fuel tank or place a piece of plastic film beneath the cap to prevent gasoline leakage.
3. Remove the two screws which hold the belt guard to the deck. See figure 25.



FIGURE 25.

4. Place the mower on its side.

WARNING

Make sure that the mower is secure and cannot tip over.

5. Remove three self-tapping screws, and one carriage bolt, lock washer and hex nut from cover plate. See figure 26. Remove the cover plate.



FIGURE 26.

6. Remove the belt from the idler pulley.
7. Remove the two self-tapping screws which hold the support bracket and idler bracket to the deck. See figure 27. A 7/16" wrench is required.



FIGURE 27.

8. Slide the support bracket and idler bracket (with idler pulley attached) off pulley shaft. See figures 27 and 28.
9. Remove belt as shown in figure 28. Reassemble in reverse order with new belt.



FIGURE 28.

NOTE

When reassembling support bracket and idler bracket, be certain springs are hooked as shown in figure 29.



FIGURE 29.

OFF-SEASON STORAGE

The following steps should be taken to prepare lawn mower for storage.

1. Clean and lubricate mower thoroughly as described in the lubrication instructions.
2. Refer to engine manual for correct engine storage instructions.
3. Coat mower's cutting blade with chassis grease to prevent rusting.
4. Follow battery storage instructions on page 14.
5. Store mower in a dry, clean area.

NOTE

When storing any type of power equipment in an unventilated or metal storage shed, care should be taken to rustproof the equipment. Using a light oil or silicone, coat the equipment, especially the bearings and cables.

HANDLE STORAGE

The handle can be stored in an upright position to take less space. Move hairpin cotters to outer hole on weld pins (see figure 2). Grasp the lower handle at the bottom and pull apart slightly. Tip the handle forward. It will lock in this position. Reverse this procedure to place the handle in the operating position.



Grass Deflector model 195-034-000 is available as optional equipment.

NOTE

The use of any accessory on this Rotary Mower other than those manfactured by the mower manufacturer is **not** recommended.

GRASS CATCHER Model 0328 is available as replacement equipment for the mower shown in this manual.

WARNING

1. DO NOT operate the mower with the chute door open unless the complete grass catcher is properly mounted on the mower.
2. DO NOT operate the mower without the protective shield on the rear of the deck in place.

NOTE

Under normal usage bag material is subject to wear and should be checked periodically. Be sure any replacement bag complies with the mower manufacturer's recommendations.

For replacement bags, use only factory authorized replacement bag No. 764-0171 (without Flip Top) or No. 764-0170 (with Flip Top).

Trouble Shooting Chart

Problem	Cause	Remedy
1 Engine fails to start	A Blade control handle disengaged	A Engage blade control handle.
	B Check fuel tank for gas	B Fill tank if empty.
	C Fuel shut-off valve closed	C Open fuel shut-off valve.
	D Spark plug lead wire disconnected	D Connect lead wire.
	E Throttle control lever not in the starting position	E Move throttle lever to start position.
	F Faulty spark plug	F Spark should jump gap between control electrode and side electrode. If spark does not jump, replace the spark plug.
	G Carburetor improperly adjusted, engine flooded	G Remove spark plug, dry the plug, crank engine with plug removed, and throttle in off position. Replace spark plug and lead wire and resume starting procedures.
	H Old stale gasoline	H Drain and refill with fresh gasoline.
	I Engine brake engaged	I Follow starting procedure.
	J Discharged battery	J Refer to battery charging instructions.
2 Hard starting or loss of power	A Spark plug wire loose	A Connect and tighten spark plug wire.
	B Carburetor improperly adjusted	B Adjust carburetor. See separate engine manual.
	C Dirty air cleaner	C Clean air cleaner as described in separate engine manual.
3 Operation erratic	A Dirt in gas tank	A Remove the dirt and fill tank with fresh gas.
	B Dirty air cleaner	B Clean air cleaner as described in separate engine manual.
	C Water in fuel supply	C Drain contaminated fuel and fill tank with fresh gas.
	D Vent in gas cap plugged	D Clear vent or replace gas cap.
	E Carburetor improperly adjusted	E Adjust carburetor. See separate engine manual.
4 Occasional skip (hesitates) at high speed	A Carburetor idle speed too slow	A Adjust carburetor. See separate engine manual.
	B Spark plug gap too close	B Adjust to .030".
	C Carburetor idle mixture adjustment improperly set	C Adjust carburetor. See separate engine manual.
5 Idles poorly	A Spark plug fouled, faulty, or gap too wide	A Reset gap to .030" or replace spark plug.
	B Carburetor improperly adjusted	B Adjust carburetor. See separate engine manual.
	C Dirty air cleaner	C Clean air cleaner as described in separate engine manual.
6 Engine overheats	A Carburetor not adjusted properly	A Adjust carburetor. See separate engine manual.
	B Air flow restricted	B Remove blower housing and clean as described in separate engine manual.
	C Engine oil level low	C Fill crankcase with the proper oil.
7 Excessive vibration	A Cutting blade loose or unbalanced	A Tighten blade and adapter. Balance blade.
	B Bent cutting blade	B Replace blade.

Note: For repairs beyond the minor adjustments listed above, contact your local authorized service dealer.

Model 376


99
100
Meets CPSC Blade Safety Requirements
Lot/Model
Mfg. Date

Model 376 PARTS LIST FOR MODEL 376 ROTARY MOWER

REF. NO.	PART NO.	COLOR CODE	DESCRIPTION	NEW PART
1	**		Hub Cap	
2	734-0874		Wheel Ass'y. Comp. 8 x 1.75—Front	
3	741-0180		Flanged Ball Brg. .500" I.D.	
4	13415		Idler Brk't. Ass'y.	
5	15244		Axle Ass'y.	
6	15246		Height Adj. Handle	
7	15247		Belt Cover	
8	15249		Rear Shaft Ass'y.	
9	15250		Bracket—Pulley Shaft	
10	710-0352		Hex B-Tap Scr. ¼ x .38" Lg.	
11	710-0456		Hex Drilling Scr. #10 x .50"	
12	710-0603		Hex Wash. Hd. B-Tap Scr. 5/16-18 x .50" Lg.	
13	710-0654		Hex Wash. Hd. TT-Tap Scr. 3/8-16 x 1.00" Lg.	
14	711-0500		Spacer .526" I.D. x .690" O.D. x .640" Lg.	
15	712-0287		Hex Nut ¼-20 Thd.*	
16	712-0342		Hex Jam Nut 3/8-16 Thd.	
17	713-0289		#48 Chain ½" Pitch x 34 Links—E.	
18	714-0104		Intern. Cot. Pin 5/16" Dia.	
19	714-0111		Cotter Pin 3/32" Dia. x 1.00" Lg.*	
20	714-0115		Cot. Pin 1/8" Dia. x 1.00" Lg.*	
21	715-0144		Spring Pin Spir. 3/16" Dia. x 1.50" Lg.	
22	720-0143		Grip—Black	
23	732-0357		Extension Spring .33" O.D. x 1.12" Lg.	
24	732-0428		Extension Spring .50" O.D. x 4.25" Lg.	
25	735-0144		Rubber Wash.	
26	736-0105		Bell-Wash. .400" I.D. x .88" O.D.	
27	736-0160		Fl-Wash. .531" I.D. x .930" O.D.	
28	736-0329		L-Wash. ¼" I.D.*	
29	736-0344		Fl-Wash. .390" I.D. x 1.00" O.D.	
30	738-0255		Shld. Bolt .375" Dia. x .181	
31	738-0501		Pulley Shaft .500" Dia.	
32	741-0248		Flange Brg. .506" I.D. Plastic	
33	741-0324		Hex Flange Brg. x .506" I.D. Plastic	
34	746-0463		Drive Clutch Cable—50" Lg.	
35	747-0351		Linkage Rod .38" Dia.	
36	748-0187		Ratchet Wheel	
37	750-0503		Spacer .395" I.D. x .503" O.D. x .562" Lg.	
38	750-0506		Spacer .75" I.D. x .88" O.D. x 1.41" Lg.	
39	750-0526		Spacer .385" I.D. x .503" O.D. x .270" Lg.	
40	754-0252		"V"-Belt ½" x 33" Lg.	
41	756-0191		Pulley w/9 Tooth Sprocket Ass'y.	
42	756-0360		Flat Idler Plastic 1.62" Dia.	
43	756-0384		"V"-Pulley .50" I.D. x 2.52" O.D.	
44	10662		Front Axle Ass'y.	
45	736-0219		Belleville Washer .40" I.D. x 1.13" O.D.	
46	711-0313		Sleeve .526" I.D. x .690" O.D. x .880 Lg.	
47	712-0200		Hex Ins. L-Nut ½-20 Thd.	
48	736-0221		Int. L-Wash. 3/8" I.D.	
49	738-0149		Shld. Bolt .625 Dia. x .425	
50	10622		Spring—Nylon	
51	712-0324		Hex Ins. L-Nut ¼-20 Thd.	
52	734-1051		Wheel Ass'y. Comp. 9.25 x 1.75 Rear	
53	741-0180		Flanged Ball Brg. .500" I.D.	
54	738-0137		Shoulder Bolt .342" Dia. x .268	
55	748-0188		Pawl	
56	726-0135		Cap Speed Nut 5/16" Rod	

*For faster service obtain standard nuts, bolts and washers locally. If these items cannot be obtained locally, order by part number and size as shown on parts list.

(462—Red Flake)

When ordering parts, if color or finish is important use the appropriate color code shown. (e.g. Red Flake Finish—14005 (462).)

**Hub Caps (Optional)	
Color	**Part No.**
Red	731-0124
Orange	731-0254
Black	731-0354
Gray	731-0355

PARTS INFORMATION

POWER EQUIPMENT PARTS AND SERVICE

Parts and service are available through the authorized service firms listed below. All orders should specify the model number of your unit, part numbers, description of parts and the quantity of each part required.

BRIGGS AND STRATTON, TECUMSEH AND PEERLESS PARTS AND SERVICE

Briggs & Stratton, Tecumseh and Peerless parts and service should be handled by your nearest authorized engine service firm. Check the yellow pages of your telephone directory under the listing **Engines—Gasoline,** Briggs & Stratton or Tecumseh Lauson.

NOTE: If any parts are found to be missing or defective upon assembly of this unit, write to advise the factory so that immediate replacement can be made.

ALABAMA
Auto Electric & Carburetor Co. — **BIRMINGHAM** — 2625 4th Ave. S. — 35233

ARKANSAS
Sutton's Lawn Mower Shop — **NORTH LITTLE ROCK** — 5301 Roundtop Drive Box 368, Rt. 4 — 72117

CALIFORNIA
Billious — **PORTERVILLE** — 75 North D Street — 93257

COLORADO
Spitzer Industrial Products Co. — **DENVER** — 6601 N. Washington St. — 80229

FLORIDA
Radco Distributors — **JACKSONVILLE** — 4909 Victor St. Box 5459 — 32207

Small Eng. Dist. — **HIALEAH** — 7995 W. 26th Court — 33016

GEORGIA
East Point Cycle & Key Inc. — **EAST POINT** — 2834 Church St. — 30344

ILLINOIS
Keen Edge Co. — **LYONS** — 8615 Ogden Ave. — 60534

INDIANA
Parts & Sales Inc. — **ELKHART** — 2101 Industrial Pkwy. — 46516

IOWA
Power Lawn & Garden Equip. — **DUBUQUE** — 2551 J.F. Kennedy — 52001

LOUISIANA
Suhren Engine Co. — **NEW ORLEANS** — 8330 Earhart Blvd. — 70118

MARYLAND
Center Supply Co. — **TAKOMA PARK** — 6867 New Hampshire Ave. — 20912

MASSACHUSETTS
Morton B. Collins Co. — **SPRINGFIELD** — 300 Birnie Ave. — 01107

MICHIGAN
Lorenz Service Co. — **LANSING** — 2500 S. Pennsylvania — 48910

Power Equipment Dist. — **MOUNT CLEMENS** — 340 Hubbard — 48043

MINNESOTA
Hance Distributing Inc. — **HOPKINS** — 420 Excelsior Ave. W. — 55343

MISSOURI
Automotive Equip. Service — **KANSAS CITY** — 3117 Holmes St. — 64109

Ross-Frazer Supply Co. — **ST. JOSEPH** — 8th and Monterey — 64503

Henzler, Inc. — **ST. LOUIS** — 2015 Lemay Ferry Rd. — 63125

NEW JERSEY
Lawnmower Parts Inc. — **BELLMAWR** — 717 Creek Rd. — 08030

NEW MEXICO
Spitzer Eng. & Parts Co. — **ALBUQUERQUE** — 1023 Third Ave. N.W. — 87103

NEW YORK
Gamble Dist., Inc. — **CARTHAGE** — West End Ave. — 13619

OHIO
Stebe's Mid-State Mower Supply — **CARROLL** — Box 366, 71 High St. — 43112

Bleckrie, Inc. — **CLEVELAND** — 7900 Lorain Ave. — 44102

National Central — **WADSWORTH** — 687 Seville Rd. — 44281

Burton Supply Co. — **YOUNGSTOWN** — 1301 Logan Ave. Box 929 — 44501

OKLAHOMA
Victory Motors, Inc. — **MUSKOGEE** — 605 S. Cherokee — 74401

OREGON
Kenton Supply Co. — **PORTLAND** — 8216 N. Denver Ave. — 97217

PENNSYLVANIA
EECO Inc. — **HARRISBURG** — 4021 N. 6th St. — 17110

Thompson Rubber Co. — **PHILADELPHIA** — 5222-24 N. Fifth St. — 19120

Bluemont Co. — **PITTSBURGH** — 11125 Frankstown Rd. — 15235

Frank Roberts & Sons — **PUNXSUTAWNEY** — R.D. 2 — 15767

Scranton Auto Ignition Co. — **SCRANTON** — 1133-35 Wyoming Ave. — 18509

TENNESSEE
Master Repair Service — **KNOXVILLE** — 2000 Western Ave. — 37921

American Sales & Service, Inc. — **MEMPHIS** — 3035-43 Bellbrook — 38116

TEXAS
Marr Brothers, Inc. — **DALLAS** — 423 E. Jefferson — 75203

Woodson Sales Corp. — **FORT WORTH** — 6733 Baker Blvd. Hwy. 10 — 76118

Bullard Supply Co. — **HOUSTON** — 2409 Commerce St. — 77003

Engine House Inc. — **SAN ANTONIO** — 8610 Botts Lane P.O. Box 17867 — 78217

UTAH
Powered Products — **BOUNTIFUL** — 485 N 500 W. — 84010

VIRGINIA
RBI Corp. — **ASHLAND** — 101 Cedar Ridge Dr. — 23005

WASHINGTON
Equip. Northwest — **SEATTLE** — 1410 14th Ave. — 98122

WISCONSIN
Horst Dist. Inc. — **CHILTON** — 444 N. Madison St. — 53014

NORTH CAROLINA
Smith Hardware Co. — **GOLDSBORO** — 515 N. George St. — 27530

Dixie Sales Company — **GREENSBORO** — 335 N. Green — 27402

WARRANTY PARTS AND SERVICE POLICY (0484)

The purpose of warranty is to protect the customer from defects in workmanship and materials, defects which are NOT detected at the time of manufacture. It does not provide for the unlimited and unrestricted replacement of parts. Use and maintenance are the responsibility of the customer. The manufacturer cannot assume responsibility for conditions over which it has no control. Simply put, if it's the manufacturer's fault, it's the manufacturer's responsibility; if it's the customer's fault, it's the customer's responsibility.

CLAIMS AGAINST THE MANUFACTURER'S WARRANTY INCLUDES:

1. **Replacement of Missing Parts** on new equipment.
2. **Replacement of Defective Parts** within the warranty period.
3. **Repair of Defects** within the warranty period.

All claims MUST be substantiated with the following information:

1. **Model Number** of unit involved.
2. **Date** unit was purchased or first put into service.
3. **Date of failure.**
4. **Nature of failure.**

MTD PRODUCTS INC • P.O. BOX 36900 • CLEVELAND, OHIO 44136